



MCGINLEY ORTHOPEDICS

ENGINEERING MEDICAL PROGRESS

INTELLISENSE Drill Technology® Quick Start Guide

WARNINGS

WARNING!

- This device is not shipped sterile.
- Sterilize drill, drill chuck, depth sensing arm, spring, spring stop, and Equalizer® before use.




WARNING!

- This product is not rated for continuous use.
- Cease use if controller or attached devices emit excessive heat.
- Do not operate drill or controller if plugs or cords have been damaged.
- Do not operate if drill or controller have been dropped or damaged.
- Return to manufacturer if any of the above have occurred.



WARNING! In Bicortical Mode:

- The auto-stop feature is enabled.
- Plunging may occur if excessive force is used in the drilling direction.
- Auto-stop ceases drill bit rotation only. Drill Bit rotation will stop when the 2nd cortex is breached.



WARNING! In Freehand Mode:

- The auto-stop feature is disabled.
- Plunging may occur if excessive force is used in the drilling direction.
- The drill rotation will not stop when the second cortex is breached.

This is not a complete list of warnings. For detailed warnings and other resources, see Instructions for Use.

OTHER RESOURCES

| | |
|-------------------------|--|
| DOCUMENTS | For detailed information on the IntelliSense Drill Technology® operation and handling, see the Instructions for Use supplied with this product. |
| STERILIZATION | See Instructions for Use to view instructions for proper, and thorough, sterilization of the IntelliSense Drill Technology®. |
| TROUBLESHOOTING | See the Instructions for Use to view the Troubleshooting table. |
| CUSTOMER SUPPORT | Phone: 307.315.6403 Email: support@mcginleyinnovations.com |
| WARRANTY | View the product warranty page by contacting customer support by phone at 307.315.6403 or by email at support@mcginleyinnovations.com . |




MCGINLEY ORTHOPEDICS

ENGINEERING MEDICAL PROGRESS

INTELLISENSE Drill Technology® Quick Start Guide

FOLLOW THESE INSTRUCTIONS:

- 1. Sterilize all Drill components & Equalizer®, before use.**
The Controller is not sterile and cannot be sterile processed.
Controller may be sterile draped for access from the sterile field.
- 2. Assemble the Drill.**
Back of Drill: Spring (plastic end 1st) and Spring Stop
Front of Drill: Depth Sensing Arm (DSA) and Drill Chuck
- 3. Insert the Drill Bit.**
Snap the plastic bushing into the end of the DSA.
Insert the drill bit through the bushing & seat the bit.
- 4. Establish power to the Controller.**
Plug the power supply cord into the Controller.
Plug the power supply cord into an approved wall outlet.
- 5. Power the Controller ON.**
Power switch is on the back of the controller.
- 6. Connect the Drill to the Controller.**
Drill Cord plug-in is on the front of the Controller.
Align the cord dot-to-dot and push to connect.
- 7. Calibrate the Drill.**
Follow the on-screen instructions.
Calibration is required when the Drill is first plugged in.
- 8. Select the Drill Bit Diameter Range.**
Change this setting throughout the case as bit size range changes.
- 9. Select a Drilling Mode.**
Bicortical Mode is the default setting.
Other Modes include Freehand, MultiCortex, & Set Depth.
- 10. Calculate and enter the Hardware Offset.**
Use the Equalizer® to calculate the Hardware Offset.
Select the Equalizer® icon on the Controller screen to enter the offset.



This is not a complete list of instructions. For detailed instructions, contact support@mcginleyinnovations.com.